



disconnect red (VCC) wire from  
FM and connect to DUPLEX

add PPM impulses  
to DUPLEX

add GND to  
DUPLEX





